



PANDA EXTRA



EASY MOP INSTRUCTION



ATTENTION PLS READ IT CAREFULLY BEFORE USING OUR EASY MOP

	<p>ATTENTION</p> <p>PLS WAIVE THE PACKAGE AND STICKERS WHEN YOU USE IT FOR THE FIRST TIME. PLS MAKE SURE THERE IS NO DAMAGE BY ARTIFICIAL FACTOR HAPPENED DURING TRANSPORTATION.</p>	<p>WARNING!</p> <p>PLS REMIND YOUR FAMILIAR YOUNGER AND OLDER KIDS, DON'T PLAY ON THE WET FLOOR, WHICH WILL LEAD TO SLIP.</p>
	<p>DON'T USE MENTAL OR COARSE RAG TO WASH THE BUCKET IN CASE OF SCRAPING.</p>	
	<p>DON'T PUT THE EASY MOP DIRECTLY UNDER THE SUNSHINE. DON'T PUT THE EASY MOP CLOSE THE FIRE TOO MUCH IN CASE OF DAMAGE.</p>	
	<p>KIDS USE EASY MOP SHOULD BE KEPT WATCHING BY ADULTS.</p>	
	<p>FALLING FROM UPPER LEVEL IS FORBIDDEN.</p>	
	<p>DON'T REPAIR, DISASSEMBLE, REMAKE THE EASY MOP BY YOURSELF.</p>	